



Air CAM Walker Boot


Instructions For User




Place the foot and leg in the foam liner and fix them snugly. Optional: Foam pads may be placed inside liner or between liner and shell for a better fit or greater comfort. If necessary, using hook attachments fix the toe cover to the liner.




Put the foot in the walker frame. Align the center of the shaft of the ankle.



Remove the cover of the support and gently press it to fit the foam liner.



Tighten and secure the straps in the order shown.



Inflate by pushing the pump. Repeat until proper compression is obtained.

Using the Air Valve for inflation: Ensure the round valve is closed by turning the valve clockwise until it is secure. Pump the air bulb until you feel pressure within the boot. For deflation, turn the round valve counter clockwise and wait for 15 seconds until air is released.